

Printer & Accessory List

23/10/2011

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
HP Professional 2000C	1	HP LaserJet 2600N (4) 2605DN (1)	5
HP Apollo 1200	1	HP LaserJet 2100 (1) 2100M (2) 2100TN (2)	5
HP Bus Inkjet 1100D	1	HP LaserJet 2200 (1) 2200D (1)	2
HP Bus Inkjet 1200D (C8154A) 1200DTWN (C8156A)	2	HP LaserJet 2200DN (12) DTN (6)	18
HP Bus Inkjet 2200 (6) 2230 (2)	8	HP LaserJet 2300 (1) 2300D (1)	2
HP Bus Inkjet 2300 (1) 2300N (6) 2300DTN (1)	8	HP LaserJet 2300L (1) 2300N (2) DN (7) DTN (8)	18
HP Bus Inkjet 2250 (1) 2250TN (1)	2	HP LaserJet 2420 (5) 2420N (14) D (2) DN (4)	25
HP Bus Inkjet 2280 TN	1	HP LaserJet 2430T (1) TN (9) DTN (6) DTN (NOB 1)	17
HP Bus Inkjet 2600 DN	0	HP LaserJet 2550L (3) 2550 N (3) LN (1)	7
HP Bus Inkjet 2800 C8174A (3) 2800DTN C8164A (2)	5	HP LaserJet 2500L (1) 2500N (1)	2
HP Bus Inkjet 3000N	0	HP LaserJet CP2025DN	1
HP CopyJet M (C3819A)	1	HP LaserJet CP1025 (CE913A/V)	3
HP CP1700	1	HP LaserJet CP1215 (1) CP1515N (4)	5
HP DJ 350C (N&B)	1	HP LaserJet P3005 (3) N (2) D(1)DN (3) P3005X (4)	13
HP DJ 400 (1) 420 (1) 450C (C8145A x 3)	5	HP LaserJet CP3505N (1) DN (2) X (6)	9
HP DJ 550C/560	2	HP LaserJet CM1015 (5) CM1017	6
HP DJ 600/DJ 660C/DJ 670C	4	HP LaserJet P1102W (CE657A)	1
HP DJ 693C/DJ 695C	2	HP LaserJet P2055DN (1) P3015DN (1)	2
HP DJ 710C (1) 720C (1) 840C (1)	3	HP LaserJet P2014(3) 15(1) N(4) D(9) DN(4) DTN(1)	22
HP DJ 845C	1	HP LaserJet CP4005DN	1
HP DJ 895CXI	1	HP LaserJet 2840	5
HP DJ 820CXI/870CXI	2	HP LaserJet 3000N (1) DN (1)	2
HP DJ 930C	3	HP LaserJet 3020 MFP (5) 3050 (1) 3052 MF (1)	7
HP DJ 920C	3	HP LaserJet 3100MFP (1) 3150 (2) 3200 (1)	4
HP DJ 940C (2), 950C (4), 960C (3)	9	HP LaserJet M1120N MFP (CC459A)	1
HP DJ 970CXI	2	HP LaserJet M2727NF	4
HP DJ 980CXI (2) 990CXI (10)	12	HP LaserJet M3035MFP (1) M3027MFP (2)	3
HP DJ 959C	2	HP LaserJet 3030MFP (1) 3055 MFP (1)	2
HP DJ 995C (Bluetooth)	3	HP LaserJet 3300 MFP (1) 3320(1) 3330 (1)	3
HP DJ 1120C	1	HP LaserJet 3390 MFP (5) 3392 MFP (2)	7
HP DJ 1125C	2	HP LaserJet 3700N (1) DN (2) DTN (2)	5
HP DJ 1160	1	HP LaserJet 3500 (1) LJ 3550 (1)	2
HP DJ 1220C	14	HP LaserJet 2700 (1) 2700N (4)	5
HP DJ 1280	8	HP LaserJet 3600N (2) DN (3)	5
HP DJ 656C	2	HP LaserJet 3800N (1) DN (2) DTN (3)	6
HP DJ 3550	0	HP LaserJet 4000	2
HP DJ 3822	0	HP LaserJet 4000N	1
HP DJ 3650	1	HP LaserJet 4000T	5
HP DJ 6122	1	HP LaserJet 4000TN	1
HP DJ 5652 (1)	1	HP LaserJet 4050	6
HP DJ 5150 (2) 5550 (1)	2	HP LaserJet 4050N	24
HP DJ 6520	1	HP LaserJet 4050TN/4050T	10
HP DJ 5940(2) 6940 (8) 6943 (1)	11	HP LaserJet 4100N	6
HP DJ 6980 (Wireless)	6	HP LaserJet 4100TN	2
HP DJ 5440	1	HP LaserJet 4100DTN with Duplex	2
HP DJ 5850	3	HP LaserJet P4515N (1)	1
HP DJ 9800	2	HP LaserJet 4200 (3) LN (1) N (7) TN (3)	14
HP Deskjet D1660	0	HP LaserJet 4200DTN with Duplex	3
HP Photosmart 1000 (1) 3110 (1) C4780 (1)	3	HP LaserJet M4345A MFP	0
HP Photosmart 7260 (1) 7660 (1)	2	HP LaserJet 4250 (8) 4250N (6) TN (12) DTN (2)	28
HP Photosmart 2410 (1) J6410 (1) 1215 (1) 2710 (1)	4	HP LaserJet 4300N (2) TN (2) DN (2) DTN (5)	11
HP Photosmart C4780 AIO (Q8380B)	1	HP LaserJet 4350(3) N(3) TN(1) DTN(5) DTNSL(2)	14
HP Photosmart C6280	1	HP LaserJet 4500/N	0
HP LaserJet 2 (1) 3D (1)	2	HP LaserJet 4500DN + 500 Sheet Tray	1
HP LaserJet 4SI	0	HP LaserJet 4550	0
HP LaserJet 4 (1) 4+ (6)	7	HP LaserJet 4600 (1) 4600N (1) 4600DN (1)	3
HP LaserJet 4L/4LM	1	HP LaserJet 4650 (4) N (4) DN (7) DTN (4) HDN (1)	20
HP LaserJet 4V	1	HP LaserJet 4700 N (4) DN (4) DTN (3)	11
HP LaserJet 5L	10	HP LaserJet 4730 MFP (Q7518A)	1
HP LaserJet 5	9	HP LaserJet 5035XS (Q7831A)	1
HP LaserJet 5N	1	HP LaserJet 8000 (2) 8000N (3) 8000DN (1)	6
HP LaserJet 5M	1	HP LaserJet 8100 (1) 8100N (10) 8100DN (1)	12
HP LaserJet 5P	1	HP LaserJet 8150 (1) 8150N (18) DN (1)	20
HP LaserJet 5SI/5SImx/5SInx	3	HP LaserJet 8500N (1)	1
HP LaserJet 6L	5	HP LaserJet 8550N (1)	1
HP LaserJet 6P (5) 6MP (1)	6	HP LaserJet 5000 (1) 5000N (2) DN (1)	4
HP LaserJet P1005 (1) P1006 (3)	4	HP LaserJet 5100 (1) N (1) TN (4) DTN (10)	16
HP LaserJet 1000 (1) 1150 (1)	2	HP LaserJet 5200TN (1) 5200DTN (1)	2
HP LaserJet 1010	1	HP LaserJet 5550N (2) DN (7) DTN (2)	11
HP LaserJet 1015 (2) 1018 (1)	3	HP LaserJet 5500 (1) N (3) DN (2) DTN (1)	7
HP LaserJet 1020	3	HP LaserJet 9000N (1) DN (3)	4
HP LaserJet 1022 (2) 1022N (5) 1022NW (2)	9	HP LaserJet 9000MFP (1)	1
HP LaserJet 1100 (3)	3	HP LaserJet 9040 (1) N (1) 9040DN (1)	3
HP LaserJet 1200 (3) 1300 (4) 1300N (2)	9	HP LaserJet 9050N	2
HP LaserJet 1320 (5) N(5) TN(3) NW(1) 1160 (5)	19	HP LaserJet 9500N	1
HP LaserJet 1500L (1) 1500 (2)	3	HP LaserJet 9500MFP (With Stacker –C8085A)	2

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
HP OfficeJet 7140CXI	2	Epson DFX 5000 (1) 5000+ (2)	3
HP OfficeJet 7110 (10) 7130 (1)	11	Epson DFX 8000	1
HP OfficeJet Pro K550 (7) DWN (2) K550DTN (3)	12	Epson DFX 8500	1
HP OfficeJet Pro K5400 (6) K8600 (1) K860DN (1)	8	Epson DLQ 3000+	2
HP OfficeJet D145 (1) D155XI (1)	2	Epson DLQ 3500	1
HP Officejet J6410	1	Epson EPL-5700	0
HP OfficeJet K7100 (2) K7103 (1)	3	Epson EPL-5800	1
HP Officejet L7680 (1) L7780 (1)	2	Epson EPL-5900L	0
HP OfficeJet G55 (1) G95 (1)	2	Epson EPL-5900	0
HP OfficeJet 6210	1	Epson EPL-6200	0
HP OfficeJet 4215 (1), 4355 (2)	3	Epson EPL-6200L	2
HP OfficeJet 9130	1	Epson EPL-N2000 (1) N2700 (1)	2
HP OfficeJet 6110 (1) 6210 (1) 6310 (3)	5	Epson EPL-N2050 (2)	2
HP OfficeJet 5510 (2) 5610 (1)	3	Epson FX 580	1
HP OfficeJet T45	1	Epson FX 870 +	1
HP OfficeJet T65	1	Epson FX 880 (1) FX 880+ (1)	2
HP PSC750C (1) PSC 2210 (1)	2	Epson FX 980	1
HP DesignJet 10PS	1	Epson FX1120	2
HP DesignJet 750C A0 (C4709B)	1	Epson FX890 (1) 2190 (1)	2
HP DesignJet 500PS (GL2) C7769B (W/O stand)	1	Epson LQ 550	1
HP DesignJet 800PS A1 (C7779C)	1	Epson LQ 670	2
Brother Fax T74	1	Epson LQ 570+	0
Brother Fax 2920	2	Epson LQ 590	1
Brother HL 10V (1) 820	2	Epson LQ 2090	0
Brother HL 1260	1	Epson LQ 2180	1
Brother HL 1030 (1) 1230 (1) 1240 (2) 1250 (2) 1270N (3)	9	Epson LX 1170 II (1), LX1180+ (1)	2
Brother HL 1430 (1) & (N&B x 1)	2	Epson LX 300+ (5) LQ300+ (NOB x 1)	6
Brother HL 1470N	1	Epson Stylus Colour 440 (1) C66 (1)	2
Brother HL 5040 (2) 5070N (1)	3	Epson Stylus Colour 1270	1
Brother HL 5140 (13) 5150D (4)	17	Epson Stylus Photo 950	1
Brother HL 5240 (3) 5250DN (2) 5270DN (4)	9	Epson C1900 Aculaser	0
Brother HL 1850 (1) 1870N (1)	2	Epson C900 Aculaser	0
Brother HL 5130 (1) 5140 (1)	2	Epson C1000 Aculaser	1
Brother HL 5170DN	1	Epson C1100 AcuLaser	0
Brother HL 5350DN (1) 5380DN (2)	4	Epson C4100DN Aculaser	1
Brother HL 2460	0	Epson C2000 Aculaser	0
Brother HL 1660/e	1	Epson CX11NF MFP Colour Laser	0
Brother HL 2030 (3) 2070N (3)	6	Epson C8600N Aculaser	0
Brother 2700CN	1	Epson CX6600	1
Brother HL-9020 MFC (1) HL-9050 MFC (1)	2	Epson Stylus 3000	0
Brother M-1209 Dot Matrix	1	Epson Stylus Pro 5000	0
Brother M-1824L Dot Matrix	1	Epson R300	0
Brother M4018	1	Epson TMU300A (1) TMU 210PD (1)	2
Brother M4318	0	Fujitsu DL3400 (1) DL1150 (1) DL 6400Pro (1)	3
Brother MFC-3320CN (N&B)	1	Kyocera KM150N (MFP)	1
Brother MFC 3820CN	1	Kyocera FS600	1
Brother MFC 7820N	2	Kyocera FS680	0
Brother MFC-8070	1	Kyocera FS1000 (4) FS1000+ (6)	10
Brother MFC-9420CN	1	Kyocera FS1010 Paper Tray PF17 (New)	0
Brother MFC 9650 (1) 9750 (1) 9880 (1)	3	Kyocera FS1010	1
Canon BJC I250	0	Kyocera FS1010N	0
Canon BJC 330	1	Kyocera FS1020D (2) FS 1030D (3)	5
Canon BJC 240/250	1	Kyocera FS1200	3
Canon BJC 5770	1	Kyocera FS1500	1
Canon BJC 2100	2	Kyocera FS1550	1
Canon BJC 5500	1	Kyocera FS1550+	0
Canon BJC 4650	1	Kyocera FS1600	1
Canon BJC 6000 (1) 7000 (1)	2	Kyocera FS1700+	1
Canon Fax L900 (1) LA380 (1)	2	Kyocera FS1750	1
Canon I 470D	1	Kyocera FS1800	1
Canon I 9950	1	Kyocera FS1800+	1
Canon LBP 460/660	2	Kyocera FS1900	5
Canon LBP 810	2	Kyocera FS1900N	0
Canon LBP 1120	1	Kyocera FS1920N	1
Canon LBP 1210 (N&B - as HP LJ1000)	1	Kyocera FS2000D (3)	3
Canon MP360 (1) MF5770 (1)	2	Kyocera FS3700+	1
Canon S200 (1) Canon S4500 (1)	2	Kyocera FS3800	1
Compuprint 925N	2	Kyocera FS3820N/DN	2
Dell 1600N MFP (2)	2	Kyocera FS3830N	1
Dell 1700 Laser (5) 1700N (2)	7	Kyocera FS3900DN	1
Dell 1710 Laser (4) 1710N (6) 1710N (NOB x 1)	11	Kyocera FS3500	0
Dell 1720 Laser (2) 1720N (1) 1720DN (10)	13	Kyocera FS3750	1
Dell 3100 CN (1) Dell 5100 CN (1) 5210N (1)	3	Kyocera FS6700	1
Dell M5200 (1) S2500 (1)	2	Kyocera FS7000 (With 1 x PF30)	0
Dell 1320 Colour Laser (NOB)	0	Kyocera FSC-5016N (1) FS-C5020N (1)	2

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
IBM 2390-001 Dot Matrix	0	OKI ML280 Dot Matrix	1
IBM 2491 Dot Matrix	1	OKI 320 Elite Dot Matrix	12
IBM 4230-102 Dot Matrix	0	OKI 320 Elite With Front Feeder & Cover	1
IBM Infoprint 1140 With IPDS	1	OKI 321 Elite Dot Matrix	20
Lexmark 2381+ (1) 2491 (1)	2	OKI 390 Dot Matrix (2) 391 (3)	5
Lexmark 4230	1	OKI 3320 (3) (USB x 9) 3390 (3)	15
Lexmark Colour Jetprinter 2070	1	OKI 3321 Dot Matrix	0
Lexmark Z13	1	OKI 3410 Dot Matrix	3
Lexmark Z640 (1) Z645 (1) Z708 (1)	3	OKI 390 Flatbed	0
Lexmark Z65 (1)	1	OKI ML 3391 Dot Matrix	0
Lexmark 3200 Inkjet	0	OKI ML 380 Dot Matrix	1
Lexmark Optra E+	1	OKI ML 385 Dot Matrix	0
Lexmark Optra E232	1	OKI ML 393 Elite Dot Matrix	0
Lexmark Optra E252DN	1	OKI ML 395 Dot Matrix	2
Lexmark Optra E210 (2) E220 (7)	9	OKI ML 520E Dot Matrix	8
Lexmark Optra E310 (2) E312 (1)	3	OKI ML 521E Dot Matrix (NOB x 1) (Used x 3)	4
Lexmark Optra E320		OKI ML 5590 (NOB) (1)	1
Lexmark Optra E321 (Black)	1	OKI ML 5521 (4)	4
Lexmark Optra E322 (18) E322N (1)	19	OKI ML 590E	1
Lexmark Optra E323N	0	OKI ML 4410	0
Lexmark Optra E332N	8	OKI 790 (24 Pin Dot Matrix)	1
Lexmark Optra E340 (1) E342N (1)	2	OKI 5335 Flat Bed	1
Lexmark Optra E350D (1) E352DN (1)	2	OKI 4540MFP	1
Lexmark Optra M410	1	OKI OL 6EX (2) 610EX (1)	3
Lexmark Optra M412	0	OKI OL 400EX	1
Lexmark Optra Colour 1200	1	OKI Page 6E	3
Lexmark Optra C710N (2)	2	OKI Page 10E (2) 10i (2) 10EX (1)	5
Lexmark Optra C752N (2) C752DN (2)	4	OKI Page 14E	1
Lexmark Optra C762N (1) C530DN (1)	2	OKI Page 16n	1
Lexmark Optra C522N (2)	2	OKI Page 20 Plus (1) Page 24N (1)	2
Lexmark Optra C532DN (1) C540N (N&B x 1)	2	OKI B4200 (1) B4250 (2)	3
Lexmark Optra T520 (2) T522N (1)	3	OKI B4400 (1) B4400 (N&B x 9)	10
Lexmark Optra C910N(1) C912DN(3)	4	OKI B4350 (4) B4350N (20)	24
Lexmark Optra R	1	OKI B4600	4
Lexmark Optra LX (1) + LXN+ (1) LXi (1), LX+ (1)	4	OKI C3200	1
Lexmark Optra S1250	1	OKI C5100N (3) C5250N (1) C5300N (1)	5
Lexmark Optra S1855	2	OKI C5400N	1
Lexmark Optra T420 (1) T420DN (1)	2	OKI C8600N	1
Lexmark Optra T430DN (8)	8	OKI C830DN (N &B)	1
Lexmark Optra T520 (3) T520N	4	OKI B6100N (1), B6200N (1)	2
Lexmark Optra T620 (2) T620N (1)	3	OKI C9200N (1) C9400N (1)	2
Lexmark Optra T630 (4)	4	OKI C9500HDN (1)	1
Lexmark Optra T632 (1) T632N (3) T632DN (1) T634N (1)	6	OKI C7200N (1) C7300N (1) Also Duplex Versions	2
Lexmark Optra T610	1	OKI C7500N	1
Lexmark Optra T612	0	OKI Fax 5700 (1) 5900 (1)	1
Lexmark Optra T614 (3) T614N (-41E x 2) (-41L x 4)	9	OKI MC860DN (1)	1
Lexmark Optra T616N	1	OKI MB260	0
Lexmark Optra T640 (13) T640N (6)	19	Olivetti PG 408 (1) PG508 (1) (as Tally T9008)	2
Lexmark Optra T642N (3) T644N (2)	5	Olivetti PR2-D10 (1) PR5 (2)	3
Lexmark Optra T622	1	Panasonic KX-P1180 (Dot Matrix)	1
Lexmark Optra R with 500 Sheet Tray	1	Panasonic KX-P2135 (Dot Matrix)	1
Lexmark W810	1	Panasonic KX-P3696 (Dot Matrix)	0
Lexmark X502N MFP	1	Panasonic KX-P7510 Laser	1
Lexmark Optra Col 45 (A3 Inkjet)	0	Panasonic UF332 Laser Fax (1) UF 560 (1)	2
Magicolor II Colour Laser	1	Samsung SF5800	1
Minolta 5430DL Colour Laser	0	Samsung ML7050 (With Duplex)	1
QMS 2300 Desklaser (1)	1	Samsung ML1450	1
QMS 2400 Desklaser (NOB)	0	Samsung ML 1710 (2) 1750 (1)	3
QMS 2530DL	0	Samsung ML1610	1
Tally 8006E	1	Samsung ML2250 (2) ML2251N (1) ML2571 (1)	4
Tally 8108N	1	Samsung ML3051N	1
Tally T9212	5	Samsung SF560	1
Tally T9005 +	1	Samsung ML4500	1
Tally T9006 (New & Boxed)	2	Samsung ML5040	1
Tally T7070	6	Samsung MFP SCF4216	1
Tally T9205 (1) T9208 (1) T9408 (3)	5	TekTronix Phaser 560 (1) 850 (1)	2
Tally T9412	0	Unisys UDS 130 (As Lexmark 4520-002)	1
Tally T9120	2	Unisys AP 9516-L2	1
Tally T9116D	1	Xerox N17 (1) N2125 (1)	2
Tally MT645	1	Xerox Docuprint P8E (1) P8EX (1)	2
Tally T6045 (2)	2	Xerox Docuprint X58C	1
Tally T2150	0	Xerox Phaser 3450	0
Tally 2030/9 (1) 2030/24 (2) 2130/9 (1) 2140 (1)	5	Xerox Phaser 8560N (1 x NOB)	1
Tally 2340/24	1	Xerox Phaser 8200N	2
NashuaTec P7016	1	Xerox Phaser 7750G	1

Printers – Others (B Grade/Cosmetic Faults)			
Model	Q	Model	Q
Brother M4318 (Missing Cover)	2	Lexmark Optra SC1275 (Low Consumables)	1
DEC LSR 2000 Col Laser	1	Lexmark Forms 2480-001 (Back Cover)	1
Canon LBP 1260	1	IBM Infoprint Color 8 (low consumables)	1
Canon L1000 Super G3 fax (Missing Trays)	0	Olivetti DM 624	1
Dell M5200 (No Tray)	1	Mannesman Tally MT290	2
Epson LX 300 Dot Matrix	1	OKI ML182 (No paper stand)	1
Epson LQ 670 (Needs Tray)	2	OKI ML 391E Dot Matrix (Cover Missing)	1
Epson LQ 2180 & 2080 (Covers Missing)	2	OKI ML 321E Dot Matrix (Cover Missing)	5
DEC LA310 (Slight Cover Damage)	0	OKI ML 393C (Cosmetics/Covers)	1
Epson Stylus Color 1520 Missing Plastic Covers	1	OKI ML 280 (Covers Missing)	1
Epson FX 880 Missing Front Panel	1	OKI B2540 MFP (Missing Flap)	1
HP Laserjet 5200TN (Missing Side Panel)	1	OKI B4540 (Cover Missing)	1
HP Laserjet 4V (Missing Front Door)	1	OKI ML 3410 Dot Matrix (Missing Covers/Worn)	2
HP Laserjet 3200 MFP (1) (Needs paper rests)	1	OKI 5590 (Missing Cover)	1
HP DJ 540	1	OKI P16N (No side panel)	1
HP DJ 6840 WFI (Needs PSU)	1	Panasonic KXP1123 (Top cover missing)	1
HP DJ 1125C (Slight Tray Damage)	1	Panasonic KX-P2624/24 Pin Dot Matrix	1
HP Officejet 5110 (Missing paper rest)	1	Panasonic KX-PS8000 Col Laser (No output tray)	1
HP LaserJet 1200 (Needs trays)	8	Samsung ML6040 (Cosmetics Poor)	1
HP OfficeJet D135	1	Sharp JX-9200	1
HP Designjet 30N (Needs Tray)	1	Star LC-15	1
HP LJ3150 (2) Missing Paper Rests	3	Tally T2055 (Cosmetics)	1
		Zebra S600 (No Print Head)	1

Accessories & Spares			
Brother DX4000 (HL2460 Duplex)	1	HP LJ P3005/M3035 Range Tray 3 (Q7817A)	2
Brother LT500 Tray (N & B)	2	HP Stacker C4785A	1
Epson FX980 Rear Tractor (1) C1900/900 Duplex (1)	2	HP 2,000 SFU (LJ9500 Range) Q1891A	1
HP LJ 4 (10) & LJ 5 (4) 500 Sheet Paper Trays	14	HP JetDirect 170X J6035A (2) 175X J6035C (1)	3
HP LJ5 Tray (C3923A) (N&B)	1	HP JetDirect 250M J6042A	1
HP LJ5 Duplex	1	HP JetDirect 500X J3265A	2
HP BI2300 250 Sheet Tray C8125-67023 (N & B)	3	HP JetDirect 400N J4100A 10/100	3
HP BI 2300 500 SFU (C8245A)	2	HP JetDirect 610N J4169A 10/100	11
HP Colour LJ5 Paper Tray (C3115A – N & B)	1	HP Jetdirect J4135A (USB)	1
HP Colour LJ5 Fuser (N&B) C3969A	1	HP JetDirect 600N J3110A (N&B)	5
HP LJ 4000 500 Sheet Feeders	5	HP JetDirect 600N J3113A	10
HP LJ 5 Envelope Feeders (N & B)	15	HP JetDirect 615N J6057A	12
HP LJ5 4MB RAM (N & B)	2	HP JetDirect 620N J7934A (20) J7934G (2)	22
HP DeskJet 1600C/CM 500 Sheet Feeder (N & B)	1	HP JetDirect 635N (J7961G)	1
HP LJ 1100A Scanner Option	2	HP JetDirect Ex-Plus (3)	3
HP LJ 1320 Tray 3 (Q5931A) (New x 5) (Grade A x 2)	7	HP JetDirect J2255 (4) J2556 (6)	10
HP LJ 4050 Formatter Boards (C4251-69001)	10	HP JetDirect J6035A	20
HP LJ 4100 Series Duplex	6	HP MFP Fax Adapter Q1314A	1
HP LJ 4100 Series 500 SFU (N&B) C8055A	3	Lexmark T640 250 Duplex (20G0887)	2
HP LJ 4500 Formatter Boards	7	Lexmark T64x 500 Duplex (20G0888)	4
HP LJ 4500 Scanners	15	IBM InfoP 1130/40 500 sht duplex (53p7946)	5
HP LJ 2550 500 SFU (Q3710A)	1	- Same as Lexmark 11K0722 (T620 500 Duplex)	
HP LJ 4500 Series 500 Sheet Feeder C4082A	6	IBM InfoP 1120-1332 250 sheet duplex (53p7947)	25
HP LJ 5000 Series 500 Sheet Feeder C4115A	7	- Same as Lexmark 11K0721 250 Sheet Duplex	
HP LJ 5000 Series 250 Sheet Feeder	5	IBM InfoP 1532/1552/1572 500 sht duplex (39v0217)	2
HP LJ 8000/8100 Series Duplex	1	Kyocera DU1 (1) DU 61 (4) Duplexers	5
HP DJ 900 Series Duplex C6463A	2	Kyocera PF5/PF20/PF75 Paper Trays	3
HP LJ 5SI Series 2,000 Sheet Bin (C6763A)	1	Kyocera HS-20 Paper Handler (N&B)	1
HP LJ 5SI Series 8-Bin Mailbox (C3764A)	1	Kyocera FK2 Fuser (N&B)	1
HP LJ 8100 Series 2,000 Sheet Bin (C4781A)	1	Kyocera MK2 (FS3500 Maint Kit - N&B)	1
HP LJ 8100 Series 2 x 500 Sheet Feeder (C4780A)	1	Kyocera PF60 Paper Trays (FS1800/3800)	1
HP LJ 5SI Duplex	1	Kyocera PF26 Trays (FS6700)	3
HP C2985B 3.2 GB Hard Drive	1	Kyocera PF21 Mini Paper Trays (New)	4
HP LJ 5SI Series 500 Sheet Tray (N & B)	3	Kyocera FE-60 (Feeder FS1800/1900)	1
HP LJ 4200/4300 1,500 Sheet Feeder (Q2444A)	12	MK-701E Maintenance Kit FS-9500DN (New)	1
HP LJ 4200/4300 Duplex	15	MK-35E Maintenance Kit FS-9000 (New)	1
HP LJ 9000 Series 2,000 SFU (C8531A)	1	PF-30A Sheet Feeder FS-7000/FS-9000 (New)	1
HP LJ 9000 Paper Path Module RG5-6227-040CN	3	Lex Marknet Pro 4034-103	1
HP LJ 8100 Series 3,000 Sheet Stack/Stapl (C4788A) NOB	0	Lex Optra T Series 250 Sheet Trays	2
HP LJ 8100 Digital Copier Assy (C4230A)	2	Lex Optra T Series 500 Sheet Trays (11K0688)	14
HP LJ 4000 500 Sheet Paper Tray (N & B)	1	Lex T762 500 SFU	1
HP LJ 4000 500 SFU (C4124A) (N&B)	1	Lex T63x 2,000 SFU	1
HP LJ 4600/4650 Series 2x500 SFU (Q3674A) (R96-5041)	3	Lexmark T612/14/16 Duplex 500 Sht (11k0722)	1
HP LJ 4V 500 Sheet Paper Tray	1	Lexmark E330/332 550 SFUs (22S0302)	2
HP LJ 2100 Tray 2 (N&B) R98-1003-000CN	1	Lexmark 4036-304 MFP X4500 Scanner	1
HP LJ 2700/3600/3800/3000 Tray (N&B) RM1-2705-060C	1	OKI C55/5950 Duplex 43347502	0
HP LJ 2600/2605 250 SFUs (Q6459A)	3	OKI ML320 Upper Tractor Feeder	1
HP LJ 3600/3505 Range 500 SFU Tray 3 (Q5985A)	1	OKI ML3321/3391 Upper Tractor Feeder	1
HP LJ P2055 Range 500 SFU Tray 3 (CE464A)	3	OKI Printheads ML3320/21 (6) ML4410 (1) (All New)	7
HP LJ 5500/5550 Tray3 500 SFU (C7130B)	2	OKI LAN 7120E	1
HP LJ 3000 Range 500 SFU Q5985A	3	OKI Serial I/F 09002351 (New & Boxed)	25

		OKI ML 3410 Printhead (New, OEM)	1
--	--	----------------------------------	---

Fax Machines

Canon Fax EB15	1	HP Fax 1230	1
Canon Fax L220	1	Canon Fax L250	1
Canon Fax L240	1	Brother Fax 2920	1
Canon Fax L140	1		

Scanners/Copiers

QMS SC-200 Scanner	1	HP Scanjet 5370 No PSU	1
HP ScanJet 6300C ADF C7670A	1	HP Scanjet 2400 No PSU	1
HP 7400C (C7710A)	1	HP Scanjet 8290 No PSU, No Paper Rest	1
HP ScanJet 8270 L1975A (No PSU)	1	Epson RIP Station 5000	1
HP Scanjet 8250 No PSU, No Paper Rest	1	Ricoh 1018 Photocopier	1
HP Scanjet 7800 No PSU	1	Lanier LD024C Colour Photocopier	1
HP Scanjet 5590 (2 PSU, 4 Scanners)	4	Kyocera KM1500 Digital Photocopier	1
HP Digital Sender 9100C (2) 9200C (1)	3		

Consumables (New) Etc

Epson DF5000/8000 Ribbon (#8766)	3	HP LJ8500/8550 Fuser (1)	1
HP LJ 4500 Fusers (N & B) 220V x 6 110V x 1	7	Lex C522/524/530/532/534 Toner - Magenta	1
HP LJ 4500 T/Fr C4196A	2	Lex C720 Photo Dev Kit 15W0904	1
HP LJ 4500 Drum (C4195A)	3	Panasonic KXP4400/5400 Drum (N & B)	1
HP LJ 5500 Toners (All 3 Colours - OEM)	3	Tally 2265/2280 Ribbon	1
OKI C7200/C7400 Toner Type C2 - Cyan	1	Tally T2130 Ribbon (1) T6xxx/T6xx Ribbon (1)	2
OKI Type 8 Toners (Page 14 Range)	10	Tektronix Phaser 540/550 Imaging Kit (N & B)	1

Grade C / Clearance Units (Open To Offers To Clear)

HP Designjet 650C A1 – No Stand (C2858B)	1	Brother HL 5140 (No Drum/Toner)	10
HP LJ 5SI (Various Minor Faults)	6	OKI ML321E (No Covers)	40
Lexmark W810N – Working, but missing Door	1	Xerox Navera 200/280 JCA-4 Finisher (As-New)	1
Digital LA30	1		

NB: XLS Version Of Online Inventory List can be downloaded from:
<http://www.cotswold-printers.com/pdfs/A-OnlineInventoryListing.xls>

Computer Printers – Terms & Definitions

The definition of second user equipment can be misleading, so to help customers understand the terminology involved we adhere to the following standard definitions:-

New & Boxed (Retail)	Equipment is in original OEM packaging with all components and consumables new and sealed as provided by the manufacturer. Where defined as Retail, these are recent models covered by manufacturers warranty and are usually sourced through the approved manufacturers <i>Distribution</i> channel.
New & Boxed (New)	Equipment is in original OEM packaging with all components and consumables new and sealed as provided by the manufacturer. Some New & Boxed items stocked may actually be obsolete, and the warranty may not be full manufacturers, but will be stated on invoice (please ask if not clear).
New Open Boxed (NOB)	Equipment is in original OEM packaging and as-new condition. Consumables may not be included as some of these items may be ex-display. As some of these may actually be obsolete, the warranty may not be full manufacturers, but will be stated on invoice (please ask if not clear).
Refurbished	The dictionary definition of Refurbishment is - <i>the state of being restored to its former good condition</i> . A Refurbished 2 nd user printer will therefore be in A1 condition and with new parts (rollers, fusers, pads, covers etc.) as appropriate to bring it back to an as-new condition. Refurbished parts have new components (e.g. fusers with new rollers or sleeves) replacing the parts that wear out. If you are buying <i>Refurbished</i> make sure it is not just cleaned up! Check out this article for more info. http://www.refurbished-electronics-guide.com/refurbished-electronics-definition.html .
Grade A	Second user equipment that is complete, cleaned, tested and generally serviced, with any apparent defective parts repaired/replaced as necessary to meet warranty requirements. Grade A units are in good cosmetic condition, allowing for normal usage and the age of the unit (some slight discolouration is normal on older printers). Grade A does not actually mean 'mint' or 'refurbished'.
Grade B	Second user equipment that is cleaned, tested and working, but may have cosmetic flaws, parts missing or minor problems which will be defined with the sale. This is a common grade for older printers where new plastic covers are unavailable or uneconomic to source at the price offered.
Grade C	Second user equipment that is sold as-is. May be working or not, but condition and terms will be stated with sale. Warranty is usually DOA (if working) or without warranty if not.
Pull	Used to describe a part or assembly pulled from a working unit for sale as a used spare part. Parts are usually cleaned, but not 'refurbished'.
Exchange Unit	Used to describe a basic printer unit without the peripheral parts (trays, external PSUs, dongles, consumables etc.) to be used to replace a faulty printer.
Consumables	Consumables are as defined by the manufacturer for specific printers, with the term usually encompassing toners, cartridges, ribbons, media, image transfer units and drums (refer to manufacturers' documentation for specific models). Once opened consumables do tend to deteriorate and therefore any used consumables provided are not normally covered by any warranty. Warranty on new consumables is as stated on the invoice. Used printers are often provided as standard without consumables ... please ask if unclear.
Distribution	Equipment manufacturers sell new equipment only through a small number of trade channels (Distributors) across Europe. Retailers (or authorised Re-Sellers) sell these to end-users and then administer (but rarely provide) warranty support, which usually is via an approved warranty provider in the country of sale.
RTB Warranty	RTB (Return To Base) Warranty is provided on the basis that the goods should be returned to us during the warranty period for examination. Repair or a replacement will be offered providing that the equipment returned is in the same condition provided (not tampered with) and failure was not attributable to wilful damage or caused by improper use.