

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
HP Bus Inkjet 2200	4	HP LaserJet CP1215(1), 1217(1), 1515N(4), 1518(1)	7
HP Bus Inkjet 2250 (1) 2250TN (1) 2280TN (1) 2300N (1)	4	HP LaserJet CP1525N (6) CP1525NW (1)	7
HP Bus Inkjet 2800 C8174A (1) 2800DTN C8164A (1)	2	HP LaserJet P3005 (1) N (4) DN (3) P3005X (4)	12
HP CP1700 Inkjet	1	HP LaserJet CM1015 (1) CM1017 (1)	2
HP DJ 640C (1) 695C (1)	2	HP LaserJet CM1312	1
HP DJ 840C (1) 843C (1) 845C (6)	8	HP LaserJet M375NW	1
HP DJ 820CXI (1) 870CXI (1)	2	HP LaserJet CM1415FNW (1) M175NW (1)	2
HP DJ 710C (1) 720C (1)	2	HP LaserJet M351A Pro 300	1
HP DJ 970CXI	0	HP LaserJet M402N (1) M402DN (2) M402DNE (1)	4
HP DJ 980CXI (2) 990C (1) 990CXI (1)	4	HP LaserJet M1212NF	2
HP DJ 9300	1	HP LaserJet M551N (3) M551DN (3)	6
HP DJ 995C (Bluetooth)	2	HP LaserJet M451DN (1) M451DW (7)	8
HP DJ 1120C	1	HP LaserJet M452NW	1
HP DJ 1125C	1	HP LaserJet M251N (1) M251NW (1)	2
HP DJ 1220C	2	HP LaserJet M425DW	1
HP DJ 1280	2	HP LaserJet M475DW (1) M476NW (2)	3
HP DJ 9300	1	HP LaserJet P2035 (1) P2055D (5) DN (19)	25
HP DJ 656C	2	HP LaserJet P1505	3
HP DJ 5150	3	HP LaserJet P4014N (1) DN (1)	2
HP DJ 3420 (2) 3840 (1)	3	HP LaserJet P4015N (2) DN(3)TN(2) X(8) 4515X(1)	16
HP DJ 3845 (1) 3940 (1)	2	HP LaserJet P2014 (14) P2015 (2) N (4) D (1) DN (4)	25
HP DJ H470WBT (Mobile Printers)	1	HP LaserJet P3015 DN	5
HP DJ 5150 (1) 5151 (2) 5552 (1)	4	HP LaserJet P1606DN	1
HP DJ 6520 (1) 6540 (1) 6840 (1)	3	HP LaserJet 3000N	1
HP DJ 5940 (1) 6943 (1)	2	HP LaserJet 3015 MFP	1
HP DJ 6980 (Wireless)	2	HP LaserJet 3150 (1) 3200 (1)	2
HP DJ 9800	0	HP LaserJet M401D (1) M401DN (5) M401DNE (1)	7
HP DJ 5440	1	HP LaserJet M401A	1
HP DJ 5850	2	HP LaserJet M1522N (1) NF (2)	3
HP DJ 2510 (CX027-64001)	1	HP LaserJet M4555 (1) M4555f (with trays) (1)	2
HP Deskjet D2360	4	HP LaserJet M601N/DN (6) M602N/DN (2) M602X(1)	9
HP Deskjet D1460 (1) D1560 (2) D7360 (1)	4	HP LaserJet M603N/DN (17) XH (1) M606DN (5)	23
HP Deskjet F380 (1) F4280 (1)	2	HP LaserJet M1120N MFP (CC459A) (1) M1319F (1)	2
HP Envy 110 (PSC) (1) Envy 5530 (1)	2	HP LaserJet M3027(1) M3035 (1)	2
HP PSC1317	1	HP LaserJet 3030 (1) 3055MF (1)	2
HP Photosmart 1000 (1) 3110 (1) 1315 (1)	3	HP LaserJet 3320 MFP (2) 3330 (1) 3380 (2)	5
HP Photosmart 2575 (1) 5510 (1)	2	HP LaserJet 3390 MFP (A x 3) (NOB x 1)	5
HP Photosmart 7260 (1) 7660 (1) 7760 (1)	3	HP LaserJet 3392 (A x 1) (NOB x 2) M2727NF/S (2)	5
HP Photosmart 2410 (1) 2510 (1)	2	HP LaserJet 3500 (1) 3550 (1)	2
HP Photosmart J6410 (1) 1215 (1) 2710 (1)	3	HP LaserJet 2700 (1) 2700N (1)	2
HP Photosmart C4180 (1) C4280 (2) C4480 (2) C4680 (1)	6	HP LaserJet 3600 (3) 3600N (10) 3600DN (1)	14
HP Photosmart C3180 (1), C5180 (1), C6180 (1)	3	HP LaserJet 3800N	9
HP Photosmart C6280 (1) C6380 (1) C7280 (1) C7680 (1)	4	HP LaserJet 3525N (7) DN (2) X (4)	13
HP Photosmart C310A (CN503B)	1	HP LaserJet CM2320NF	1
HP Photosmart D5160	2	HP LaserJet CP4025DN (2) CP4525N (1)	3
HP Photosmart Premium Fax (CC335B)	1	HP LaserJet CP5225N	3
HP LaserJet 6L	0	HP LaserJet 5200DTN	2
HP LaserJet 4 (1) 4V (1)	2	HP LaserJet 4000 (2) N (8) T (5) TN (1)	16
HP LaserJet 5	9	HP LaserJet 4050 (1) 4050N (1)	2
HP LaserJet 5N	4	HP LaserJet 4050TN/4050T	2
HP LaserJet 5P	0	HP LaserJet 4100N (5) 4100TN (2) 4100DTN (2)	9
HP LaserJet P1005 (3) P1006 (4)	7	HP LaserJet 4200 (1) LN (1) N (10) TN (9)	31
HP LaserJet P1102W	16	HP LaserJet 4200DTN with Duplex	19
HP LaserJet 1000	7	HP LaserJet M5025 (1) M5035X (1) M5035XS (1)	3
HP LaserJet 1010 (2) 1012 (1)	3	HP LaserJet M506DN (1) M525F (2)	3
HP LaserJet 1020	1	HP LaserJet M575DN	1
HP LaserJet 1022	0	HP LaserJet CM4540FSKM	1
HP LaserJet 1100	2	HP LaserJet 4345MFP (2) M4345MFP (2)	4
HP LaserJet 1300	1	HP LaserJet 4250 (10) 4250N (2) TN (1) DTN (8)	21
HP LaserJet 1320 (3) N (4) TN (1) 1160 (1)	9	HP LaserJet 4300N (2) TN (2) DN (2) DTN (5)	11
HP LaserJet 2100M (1) 2100TN (1)	2	HP LaserJet 4350(1) N(2) TN(1) DTN(3) DTNSL(1)	8
HP LaserJet 2200 (1) 2200D (3) 2200DN (2)	6	HP LaserJet 4600N (1) DN (2) DTN (1)	4
HP LaserJet 2820MFP (1) 2840MFP (3)	4	HP LaserJet 4650 (4) N (2) DN (2) HDN (1)	9
HP LaserJet 1600(1) 2600N(7) 2605(1) DN(3)	12	HP LaserJet 4700N (3) DN (2) DTN (3)	8
HP LaserJet 2300 (2) D(2) L(1) N(1) DN(5) DTN(1)	12	HP LaserJet 4730 MFP (Q7518A)	1
HP LaserJet 2420 (4) 2420N (6) D (2) DN (1)	13	HP LaserJet 8000 (2) 8000N (1) 8000DN (1)	4
HP LaserJet 2430T(1) TN (1) DTN (3)	5	HP LaserJet 8100 (1) 8100N (8) 8100DN (2)	11
HP LaserJet 2550L (2) 2550 N (2) LN (2)	6	HP LaserJet 8150 (1) 8150N (9) DN (2)	12
HP LaserJet CP1025 (5) 1025NW (1) CP4005N (2) DN (1)	6	HP LaserJet 5550N (2) DN (4) DTN (8) HDN (1)	15
HP LaserJet CP2025 (1) CP2025N (6) DN (6)	13	HP LaserJet 5500N (1) DN (3) DTN (1)	5
HP LaserJet CP3505N (4) DN (3) X (2)	9	HP LaserJet 9000N (2) DN (1) 9000MFP (1)	4
		HP LaserJet 9050MFP (1) M9050MFP (1)	2
		HP LaserJet 9040N (2) DN (2), 9050DN (4)	8
		HP LaserJet CP6015XH	0
		HP LaserJet CM6030MFP (1) CM6030FMFP (1)	2
		HP LaserJet CM6040MFP (1) CM6040FMFP (1)	2
		HP LaserJet M775F (2) 9500N (1)	3

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
HP OfficeJet 7000 (1) 7500A (1) 7612 (1)	1	Epson DFX 5000	1
HP OfficeJet 4500 Desktop (1), 4500W (1)	2	Epson DFX 8000	1
HP OfficeJet K80 (1) K7100 (1)	2	Epson DFX 8500	0
HP OfficeJet J3680 (1) J5780 (1) J4580 (2)	4	Epson DLQ 3000+	0
HP OfficeJet L7480 (1) L7580 (1) L7680(2) L7780 (1)	5	Epson DLQ 3500	0
HP OfficeJet K550DTN (1) K850DN (2) K8600DN (2)	5	Epson EPL-5700	0
HP OfficeJet 8500A+ (3) 8500 Wireless (1)	4	Epson EPL-5900L	0
HP OfficeJet Pro 8100	1	Epson EPL-3000N	0
HP OfficeJet 6000 Pro (1) 8000 Enterprise (2)	3	Epson EPL-N2000	0
HP OfficeJet 6210 (1) 6500A Plus (1)	2	Epson FX580 (1) FX870 (2)	3
HP OfficeJet 7210 (1) 7310 (1)	2	Epson FX2190 (1) LQ2180 (1)	2
HP OfficeJet 4215 (2), 4315 (2), 4255 (1), 4355 (3)	8	Epson FX1170 (1), FX1180+ (1)	2
HP OfficeJet 6110 (1) 6210 (1)	2	Epson LQ550 (1) LQ570+ (1)	2
HP OfficeJet 5510	2	Epson LQ300+II	0
HP PSC750C (1) PSC 1610 (2) PSC2115 (1)	4	Epson LQ670	2
HP DesignJet 10PS	1	Epson LQ850	1
HP DesignJet 500 (C7769B) (1) 510PS (CJ996A) (1)	2	Epson LQ590	0
HP DesignJet 750C+ (C4709B)	1	Epson LQ2080 (2) LQ2070 (1)	3
HP DesignJet 800PS (C7780C)	1	Epson FX2170	2
HP DesignJet 1050C+ (C6074B)	1	Epson LX1180+	1
Brother Fax 8220 (1) Fax 2820 (1) 8360P (1)	3	Epson LQ300+	0
Brother DCP-L5500DN	1	Epson LQ300 (NOB)	1
Brother DCP-8025D MFP (1) DCP-9055CDN (1)	2	Epson M1200 Mono Laser	0
Brother DCP-7030 (1) DCP-8070D (2)	3	Epson C1000 Aculaser	1
Brother DCP-7055	1	Epson M2000 Mono Laser	1
Brother DCP-7025(1) 7065DN(1) 9010CN(1) 9020CDW(1)	4	Epson C2800DN	1
Brother HL 1230	1	Epson CX17NF MFP Colour Laser	0
Brother HL 1430 (N&B x 1)1450 (1)	2	Epson C9100 AcuLaser	1
Brother HL 5070N	1	Epson TMU300A (1) TMU 210PD (1)	2
Brother HL 5130 (9) 5140 (3)	12	Fujitsu DL3400 (1) DL1150 (1)	2
Brother HL 5240 (4) 5240L (2) 5250DN (2) 5280DW (2)	10	Kyocera FS600	1
Brother HL 1650 (1) 1850 (1) 1870N (1) 6050DN (1)	4	Kyocera FS920	1
Brother HL 5340DL (5) 5340D (3) 5350DN (1)	9	Kyocera FS1000 (4) FS1000+ (6)	10
Brother HL 5380DN	2	Kyocera FS1010 Paper Tray PF17 (New)	0
Brother HL 5440D (7) 5450DN (2) 5470DW (1)	10	Kyocera FS1010	1
Brother HL 2030	1	Kyocera FS1010N (1) FS1020D (2)	3
Brother HL 2140 (1) 2170W (1)	2	Kyocera FS1030D (3) DN (2)	5
Brother HL L2300D	7	Kyocera FS1050 (1) FS1080 (1)	2
Brother HL 2240 (1) 2250DN (1)	2	Kyocera FS1041 (1) FS1061DN (3)	4
Brother HL 3040CN (1)	2	Kyocera FS1100	1
Brother HL 4040CN (2) HL 4050CDN (2)	4	Kyocera FS1200	3
Brother HL 4140CN (1) HL 4150CDN (1)	2	Kyocera FS1350DN (1) FS1370DN (1)	2
Brother HL 9050 MFC (1) 9042CDN (1)	2	Kyocera FS1550	1
Brother HL 4570CDW (1) 6180DW (1) 8460DN (1)	3	Kyocera FS1320MFP (1) FS1135MFP (1)	2
Brother M-1209 Dot Matrix (1) M-1824L Dot Matrix (1)	2	Kyocera FS1600	1
Brother MFC-3320CN (N&B x 1) MFC 3820CN (1)	2	Kyocera FS1700+	1
Brother MFC-7360N	0	Kyocera FS1750	2
Brother MFC-7225N (1) 7820 (1) 7840 (1)	3	Kyocera FS1800	1
Brother MFC 8065DW	1	Kyocera FS1800+	1
Brother MFC-8460-UK (1) MFC-8460-Fr (1)	2	Kyocera FS1900	0
Brother MFC-8220	1	Kyocera FS1920	1
Brother MFC-8840DN (1) 8870DW (1)	2	Kyocera FS2000D (1) FS2000DN (1)	2
Brother MFC-9120CN	2	Kyocera FS2020DN	3
Brother MFC-9330CDW (2) 9055CDN (1) 9070 (2)	5	Kyocera FS2100DN	6
Brother MFC-9650 (1) 9750 (1) 9880 (1) 9840CDW (1)	4	Kyocera FS3700+	2
Brother MFC-9460 (1) MFC-9465 (1)	2	Kyocera FS3800	3
Canon MP 390 Smartbase	1	Kyocera FS3820DN	1
Canon I 470D	1	Kyocera FS3830N	0
Canon LBP 460/660	2	Kyocera FS3900DN	1
Canon LBP 3360DN (1) LBP6670DN (22)	23	Kyocera FS3920DN	2
Canon LBP 810 (2) LBP3000 (1)	3	Kyocera FS4000DN (1) FS4100DN (13)	14
Canon LBP6310DN (1) LBP6680X (6)	7	Kyocera FS4020DN	2
Canon LBP7680C	1	Kyocera FS4200DN (9) FS430DN (1)	10
Canon MF5570 (1) MF5940DN (1) MF8350DN (1)	3	Kyocera FS3750	1
Canon MP360 (1) MFP5750 (1) MFP5770 (1) MX350 (1)	41	Kyocera FS6950DN	1
Dell 1600N MFP	5	Kyocera FSC-5016N (1) 5020DN (4) 5030N (1)	6
Dell 1700 Laser (4) 1700N (1)	5	Kyocera FSC-5200DN	1
Dell 1710 Laser (1) 1710N (4) 1710N (NOB x 1)	6	Kyocera FSC-5350DN	1
Dell 1720 Laser (4) 1720DN (6)	10	Kyocera FSC-5100DN (1) 5200DN (1)	2
Dell P1500 (Grade B x 1) 1130N (1)	2	Kyocera FS-P2135DN	0
Dell 2150CN(1) 2330D (1) 2330DN (1)	3	Kyocera M2030DN	1
Dell 3330DN	1		
Dell 3100CN (6) 3010CN (1)	7		
Dell 5100CN (1) 5210N (1)	2		
Dell 5130CDN	0		
Dell M5200 (1) B5465DN (1)	2		
Dell B5460DN	1		
Dell 5330DN	1		
Dell 2135CN MFP (2)	2		
Dell 2360DN	0		
Dell 1320CN (1) 3110CN (2)	4		

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
IBM 2381 Dot Matrix	1	OKI ML3391 Dot Matrix	1
IBM Infoprint 1512 (1) 1552 (1) 1634 (1) 1532 (1)	1	OKI ML380 Dot Matrix	1
Lexmark 2380+ (1) 2580N (1)	2	OKI ML385 Dot Matrix	0
Lexmark 4230	1	OKI ML3410 Dot Matrix	7
Lexmark Z13	1	OKI ML395 (1) ML395C Dot Matrix (1)	2
Lexmark Z640 (1) Z645 (1) Z708 (1)	3	OKI ML590 Dot Matrix	1
Lexmark Z65 (1)	1	OKI ML521E Dot Matrix	1
Lexmark Optra E260D (New, Open 110V)	1	OKI ML5520	0
Lexmark Optra E+	1	OKI ML5521-ECO	5
Lexmark E210 (2) E220 (4)	6	OKI ML5591	0
Lexmark E310	1	OKI ML520E	0
Lexmark E120N	1	OKI ML591E	1
Lexmark E360DN	1	OKI MB280 (MFP)	0
Lexmark E323	4	OKI 790 (24 Pin Dot Matrix)	1
Lexmark E330 (3) E332N (10)	13	OKI 5335 Flat Bed	1
Lexmark E340 (1) E350D (2)	3	OKI 4540MFP	1
Lexmark E360D (2) E450DN (1) E460DN (2)	5	OKI MB460 (1) MB470 (1)	2
Lexmark CS7360DN	1	OKI MC361DN (1) MC362DN (1)	2
Lexmark Optra C710N	2	OKI MC363DN New Retail	1
Lexmark Optra C750N (1) C762N (1)	2	OKI MC860DN	2
Lexmark C734DW (N&B)	1	OKI Page 24N	1
Lexmark C736DN	1	OKI B2200	2
Lexmark Optra C522N (2) C530DN (1) C532N (1)	4	OKI B4100 (1) B4350N (1)	2
Lexmark C543N (1) C543DN (1) C546DTN (12)	14	OKI B401DN (2) B401D (1) B440DN (3)	6
Lexmark CS725DE (N&B)	2	OKI B430D	1
Lexmark MX310DN	1	OKI B431DN+	1
Lexmark Optra T520 (2) T522N (1)	3	OKI B4400	2
Lexmark Optra C910N (1) C925DE (1)	2	OKI C110 (1), C130DN (1) C310DN (1)	3
Lexmark Optra MS812DE	3	OKI C3100 (1) C3200 (2) C3300N (1)	4
Lexmark Optra LX (1) + LXN+ (1) LXi (1), LX+ (1)	4	OKI C3530MFP	1
Lexmark Optra S1255	0	OKI C5100N (3) C5200N (2) C5250N (1) C5300N (1)	7
Lexmark Optra S1855	0	OKI C5450N (1) C5650N (3) C5750N (2) C5850N (3)	9
Lexmark Optra T420DN	1	OKI C5900N	1
Lexmark Optra T430DN	2	OKI B6500D (1) B6500DN (1)	2
Lexmark Optra T520 (1) T520N (1)	2	OKI B6100N (1) B6200N (2) B6250 (3) B6300N (2)	8
Lexmark Optra T620	0	OKI B721N (2) B930N (1)	3
Lexmark Optra T630N	0	OKI C511DN	2
Lexmark Optra T632 (1) T632N (3) T632DN (1)	5	OKI C710N	0
Lexmark Optra T622	1	OKI C801N (1) C810N (1) C810DN (1) C821N (2)	5
Lexmark Optra T614	1	OKI C830N/DN	1
Lexmark Optra T652N	1	OKI C822N	0
Lexmark Optra TS650N/DN	3	OKI C8600N/DN (1) C8800N/DN	2
Lexmark Optra T640 (4) T640N (2)	6	OKI C9200N (1) C9400N (1)	2
Lexmark Optra T642DTN With Mailboxes	1	OKI C9655DN	0
Lexmark Optra T644N	1	OKI C7400N (1) C7500N (1) Also DN's	2
Lexmark X642E MFP (1) XS796DTE (1)	2	OKI ES2322 Colour LED	2
Lexmark X215 MFP (1) X502N MFP (1)	2	Olivetti PG 408 (1) PG508 (1) (as Tally T9008)	2
Lexmark XS544DN Col MFP	2	Olivetti PR2-D10	1
Lexmark XS548 Col MFP	1	Panasonic KX-P1180	1
Minolta 2430DL	1	Panasonic KX-P7510 Laser	1
Minolta 2590MF	1	Panasonic UF332 Laser Fax (1) UF 560 (1)	2
Minolta 5340DL	1	Ricoh Aficio MP171	1
Tally 8108N	1	Ricoh Aficio SG3100SNW	1
Tally T9005 +	1	Ricoh SP100 (New)	1
Tally T9006 (New & Boxed)	2	Ricoh SP2035 (New)	2
Tally T9205 (1) T9208 (1) T9408 (3)	5	Ricoh SP4210N/DN	1
Tally T2150	1		
Tally T2340/9	1		
Tally T6045 (1) T6050 (1)	2		
Tally 2030/9	3		
Tally 2055	1		
Tally 2170	1		
Tally 2240/24	1		
Tally T2340/9	1		
OKI 320 Elite Dot Matrix	28		
OKI 320 Elite With Front Feeder & Cover	1		
OKI 321 Elite Dot Matrix	3		
OKI 390 Dot Matrix (1) 391 (3)	4		
OKI 3320-USB (40) 3320-ECO (20)	6		
OKI 3321 (7) 3321-ECO (2)	9		
OKI 3390	2		
OKI 4410 Dot Matrix (NOB) + 1 Grade A	2		

Printers – Grade A, OR New & Boxed (N&B), As New Open Box (NOB), Or Refurbished (Ref)			
Model	Q	Model	Q
Samsung CLP 300 Colour Laser	1	Sato CL412 Label Printer	1
Samsung CLP 315W	2	Xerox N17	1
Samsung CLP 320	0	Xerox Docuprint P8E (1) P8EX (1)	2
Samsung CLP 325W	0	Xerox Docuprint X58C (1) WP-4515DN (1)	2
Samsung CLP 350N	1	Xerox Phaser 3150	1
Samsung CLP 360	1	Xerox Phaser 4500N (4) 4500DN (2) 4500DTN (1)	7
Samsung CLP 365W	0	Xerox Phaser 4510DN	4
Samsung CLP 415N	1	Xerox Phaser 6125N	1
Samsung CLP 610DN (CLP 610ND)	0	Xerox Phaser 7750G	1
Samsung CLP 620DN (CLP 620ND)	1	Xerox Phaser 7300DN	1
Samsung CLP 660DN (CLP 660ND)	1	Xerox Phaser 6280N	1
Samsung CLP 670DN (CLP 670ND)	1	Xerox 8560MFP	0
Samsung CLP 680DN (CLP 680ND)	1	Zebra LP2442 (3) Z4000 (1)	4
Samsung CLX2160	1	Zebra ZM400 (300dpi)	0
Samsung CLX3170N	1	Zebra Z6M	1
Samsung CLX3185FW	0	Intermec E4 Label Printer	1
Samsung CLX3185W	1	Brady BP-PR 300+ Label Printer	1
Samsung CLX4195FN	1		
Samsung CLX6220FX	1		
Samsung CLX6260	1		
Samsung ML 1450	0		
Samsung ML 1520	0		
Samsung ML 1610 (1) 1640 (1)	2		
Samsung ML 1665	1		
Samsung ML 1710 (1) 1910 (1)	2		
Samsung ML 1915	1		
Samsung ML 2010	2		
Samsung ML 2010R	3		
Samsung ML 2151N	1		
Samsung ML 2240	0		
Samsung ML 2250	0		
Samsung ML 2251N	0		
Samsung ML 2510	0		
Samsung ML-2825ND	2		
Samsung ML 2850D (1) 2850N (1)	2		
Samsung ML 2855ND	1		
Samsung ML 2955ND	1		
Samsung ML 3015N	3		
Samsung ML 3051N (3) 3051ND (1)	4		
Samsung ML 3310ND	5		
Samsung ML 3471ND	10		
Samsung ML 3561N	3		
Samsung M3820ND	3		
Samsung ML 4050N	3		
Samsung ML 4551ND	0		
Samsung ML 5515ND	0		
Samsung ML-6510ND	0		
Samsung ML 6040	0		
Samsung 520 Sheet Tray For CLP 770/775	1		
Samsung SCX-4520	0		
Samsung SCX-4724FN	1		
Samsung SCX-4725FN (1) 4824 (1)	2		
Samsung SCX-4825FN (1) 4828FN (1)	2		
Samsung SCX-4833FD	1		
Samsung SCX-5530FN	0		
Samsung SF 515 Fax	1		
Samsung SF 5100 Fax	0		
Samsung SF 560R Fax	1		
Samsung SF 650 Fax	1		
Samsung SF 5800 Fax	0		
Samsung SF 6800 Fax	0		

Printers – Others (B Grade/Cosmetic Faults)			
Model	Q	Model	Q
Canon LBP 1260	1	Olivetti DM 624	1
Dell M5200 (No Tray)	1	OKI ML182 (No paper stand)	1
Epson FX 2180 Dot Matrix (Missing Plastics)	1	OKI ML 391E Dot Matrix (Cover Missing)	1
Epson LQ 670 (Needs Tray)	2	OKI ML 280 (Covers Missing)	1
Epson LQ 2180 & 2080 (Covers Missing)	2	OKI B2540 MFP (Missing Flap)	1
Epson FX 1170 Missing Front Panel	1	OKI B4540 (Cover Missing)	1
HP Laserjet 5200TN (Missing Side Panel)	1	OKI P16N (No side panel)	1
HP Laserjet 4V (Missing Front Door)	1	Panasonic KXP1123 (Top cover missing)	1
HP Laserjet 3200 MFP (1) (Needs paper rests)	1	Panasonic KX-P2624/24 Pin Dot Matrix	1
HP DJ 1125C (Slight Tray Damage)	1	Samsung ML6040 (Cosmetics Poor)	1
HP Officejet 5110 (Missing paper rest)	1	Cognitive DelSoLX LDT-42 (Thermal)	2
HP OfficeJet D135	1		

Accessories & Spares			
Brother DX4000 (HL2460 Duplex)	1	HP CP4025/4525 Tray 3/Cabinet (CC422A)	1
Brother LT500 Tray (2) LT5400 (1)	3	HP Bus Ink 2800 Duplex C8258A	6
Epson FX980 Rear Tractor (1) C1900/900 Duplex (1)	2	HP JetDirect 170X	40
HP LJ 4 (10) & LJ 5 (4) 500 Sheet Paper Trays	14	HP JetDirect 175X J6035A (1) J6035G (2)	3
HP LJ5 Tray (C3923A) (N&B)	1	HP JetDirect 250M J6042A	1
HP BI2300 250 Sheet Tray C8125-67023 (N & B)	3	HP JetDirect 500X (J3265A x 1)	1
HP BI 2300 500 SFU (C8245A)	2	HP JetDirect 400N J4100A 10/100	3
HP Colour LJ5 Paper Tray (C3115A – N & B)	1	HP JetDirect 610N J4169A 10/100	11
HP Colour LJ5 Fuser (N&B) C3969A	1	HP Jetdirect J4135A (USB)	1
HP LJ 4000 500 Sheet Feeders	5	HP JetDirect 600N J3110A (N&B)	5
HP LJ 5 Envelope Feeders (N & B)	15	HP JetDirect 600N J3113A	10
HP LJ5 4MB RAM (N & B)	2	HP JetDirect 615N J6057A	12
HP DeskJet 1600C/CM 500 Sheet Feeder (N & B)	1	HP JetDirect 620N J7934A (20) J7934G (5)	25
HP LJ 1320 Tray 3 (Q5931A) (New x 5) (Grade A x 2)	7	HP JetDirect 310X	1
HP LJ 4050 Formatter Boards (C4251-69001)	10	HP JetDirect Ex-Plus (3)	3
HP LJ 4100 Series Duplex	1	HP JetDirect J2255 (4) J2556 (6)	10
HP LJ 4100 Series 500 SFU (N&B) C8055A	3	HP MFP Fax Adapter Q1314A	1
HP LJ 8500/8550 Fuser Kit (N&B) C4156A	1	Lexmark T640 250 Duplex (20G0887)	0
HP LJ 4500/4550 Transfer Kit (N&B) C4196A	3	Lexmark T64x 500 Duplex (20G0888)	4
HP LJ 4500/4550 Fuser Kit (N&B) C4198A	3	Lexmark T64x Feeder/Tray (250 Sheet)	1
HP LJ 2550 500 SFU (Q3710A)	1	Lexmark T640x 2,000 Feeder (20G0893)	0
HP LJ 4500 Series 500 Sheet Feeder C4082A	6	Lexmark T650 250 Sheet Duplex (30G0806)	1
HP LJ 5000 Series 500 Sheet Feeder C4115A	7	IBM InfoP 1130/40 500 sht duplex (53p7946)	4
HP LJ 5000 Series 250 Sheet Feeder	5	- Same as Lexmark 11K0722 (T620 500 Duplex)	
HP LJ 8000/8100 Series Duplex	1	IBM InfoP 1120-1332 250 sheet duplex (53p7947)	22
HP DJ 900 Series Duplex C6463A	2	- Same as Lexmark 11K0721 250 Sheet Duplex	
HP LJ 5SI Series 2,000 Sheet Bin (C6763A)	1	IBM InfoP 1532/1552/1572 500 sht duplex (39v0217)	2
HP LJ 5SI Series 8-Bin Mailbox (C3764A)	1	Lexmark E260/360/460 Sheet Feeders (34S0550)	18
HP LJ 8100 Series 2,000 Sheet Bin (C4781A)	1	Lexmark C546 550 SFU (3051710)	3
HP LJ 4600 Fuser Kit (RG5-6517-190CN) New, Open	1	Lexmark C54x Sheet Feeders (3063958)	16
HP LJ 5SI Duplex	1	Kyocera DU1 (1) DU 61 (4) Duplexers	5
HP LJ 3525 SFU (Tray 3) x 2 CE522A, (Also 2, NOB)	4	Kyocera PF5/PF20/PF75 Paper Trays	3
HP LJ 5SI Series 500 Sheet Tray (N & B)	3	Kyocera HS-20 Paper Handler (N&B)	1
HP LJ 4200/4300 1,500 Sheet Feeder (Q2444A)	12	Kyocera FK2 Fuser (N&B)	1
HP LJ 4200/4300 Duplex	15	Kyocera MK2 (FS3500 Maint Kit - N&B)	1
HP LJ 9000 Series 2,000 SFU (C8531A)	1	Kyocera PF60 Paper Trays (FS1800/3800)	1
HP LJ 9000 Paper Path Module RG5-6227-040CN	3	Kyocera PF26 Trays (FS6700)	3
HP LJ 4600 Series Fuser (NOB) (C9726A)	1	Kyocera PF17 Tray (New)	1
HP LJ 8100 Digital Copier Assy (C4230A)	2	Kyocera PF21 Mini Paper Trays (New)	4
HP LJ 4000 500 Sheet Paper Tray (N & B)	1	Kyocera PF320 Tray	1
HP LJ 4000 500 SFU (C4124A) (N&B)	1	Kyocera FE-60 SFU (FS1800/1900)	1
HP LJ 4250 500 Sheet Stacker (Q2442B)	1	MK-701E Maintenance Kit FS-9500DN (New)	1
HP LJ 4600/4650 Series 2x500 SFU (Q3674A) (R96-5041)	3	MK-35E Maintenance Kit FS-9000 (New)	1
HP LJ 4250 Stapler/Stacker (Q2443B)	1	PF-30A Sheet Feeder FS-7000/FS-9000 (New)	1
HP LJ 2100 Tray 2 (N&B) R98-1003-000CN	1	Lex Marknet Pro 4034-103	1
HP LJ 2700/3600/3800/3000 Tray (N&B) RM1-2705-060C	1	Lex Optra T Series 250 Sheet Trays	2
HP LJ 2600/2605 250 SFUs (Q6459A)	3	Lex Optra T Series 500 Sheet Trays (11K0688)	14
HP LJ 3600/3505 Range 500 SFU Tray 3 (Q5985A)	1	Lex T762 500 SFU	1
HP LJ P2055 Range 500 SFU Tray 3 (CE464A)	1	Lex T63x 2,000 SFU	1
HP LJ 5500/5550 Tray3 500 SFU (C7130B)	2	Lexmark T612/14/16 Duplex 500 Sht (11k0722)	1
HP LJ 3000 Range 500 SFU Q5985A	3	Lexmark E330/332 550 SFUs (22S0302)	2
HP LJ P3005/M3035 Range Tray 3 (Q7817A)	5	Lexmark 4036-304 MFP X4500 Scanner	1
HP LJ8000 Mailbox C4785A	1	OKI C55/5950 Duplex 43347502	1
HP 2,000 SFU (LJ9000 Range) Q1891A	2	OKI ML320 Upper Tractor Feeder	1
HP LJ8100 MFP Kit (C4166B) (N&B)	1	OKI ML3321/3391 Upper Tractor Feeder	1
HP LJ P4015 Range Stapler/Stacker (CB522A)	1	OKI Printheads ML3320/21 (6) ML4410 (1) (All New)	7
HP CM45 Range Stapler/Stacker (CC424A)	1	OKI LAN 7120E (2) LAN 7130E (1)	12
HP CM6030 Range Stapler/Stacker (Q6998A)	2	OKI Serial I/F 09002351 (New & Boxed)	25
		OKI ML 3410 Printhead (New, OEM)	1
		OKI B6200/6300 550 SFU (42588503)	1
		Samsung S775A 520 SFU (Fits CLP 770/775)	1

Fax Machines			
Canon Fax EB15	1	HP Fax 1230	1
Canon Fax L220	1	Canon Fax L100	1
Canon Fax L240	1	Canon Fax L250	1

Scanners/Copiers			
HP Scanjet 7500 with PSU	1	HP Scanjet N631	1
HP ScanJet 6300C ADF C7670A	1	HP Scanjet 5300 No PSU	1
HP 7400C (C7710A)	1	HP Scanjet 2400 No PSU	1
HP Scanjet 8290	1	HP Scanjet 4850	1
HP Scanjet 8250 (No PSU)	2	HP Digital Sender 9200C	1
HP Scanjet 7650	2	HP Digital Sender 9250C	1
HP Scanjet 7800 No PSU	1	Epson RIP Station 5000	1
HP Scanjet 5530	1	Lanier LD024C Colour Photocopier	1
HP Scanjet 5590 (1 PSU, 2 Scanners)	2	Kyocera KM1500 Digital Photocopier	1
HP Scanjet 5590P	1		

Consumables (New) Etc			
Epson DF5000/8000 Ribbon (#8766)	3	HP LJ8500/8550 Fuser (1)	1
HP LJ 4500 Fusers (N & B) 220V x 4 110V x 1	5	HP LJ8500 OEM Toners Black (1) Cyan (1)	2
HP LJ 4500 T/Fr C4196A	3	Lex C522/524/530/532/534 Toner - Magenta	2
HP LJ 4500 Drum (C4195A)	0	Lex C720 Photo Dev Kit 15W0904	1
HP LJ 5550 Fuser (Q3984A) 110V	1	Panasonic KXP4400/5400 Drum (N & B)	1
HP LJ 5550 Fuser (Q3985A) 220V	1	Tally 2265/2280 Ribbon	1
OKI C7200/C7400 Toner Type C2 - Cyan	1	Tally T2130 Ribbon (1) T6xxx/T6xx Ribbon (1)	2
OKI Type 8 Toners (Page 14 Range)	7	Tektronix Phaser 540/550 Imaging Kit (N & B)	1
		Xerox 7400 Transfer 101R00421	1
		Xerox 7400 Fuser 115R00038	1
		Xerox 7400 Yellow Imaging Unit 108R00649	1

Grade C / Clearance Units (Open To Offers To Clear)			
HP Designjet 650C A1 – No Stand (C2858B)	1	Lexmark X734 (No PSU)	1
Lexmark X646E (Missing Panel, ADF/Scanner OK)	1	Brother HL 5140 (No Drum/Toner)	14
Lexmark C925DTE (Needs Fuser & Cons)	1	Zebra S600 (No Print Head)	1

Special Interest Printers			

NB: XLS Version Of Online Inventory List can be downloaded from:
<http://www.cotswold-printers.com/pdfs/A-OnlineInventoryListing.xls>

Computer Printers – Terms & Definitions

The definition of second user equipment can be misleading, so to help customers understand the terminology involved we adhere to the following standard definitions:-

New & Boxed (Retail)	Equipment is in original OEM packaging with all components and consumables new and sealed as provided by the manufacturer. Where defined as Retail, these are recent models covered by manufacturers warranty and are usually sourced through the approved manufacturers <i>Distribution</i> channel.
New & Boxed (New)	Equipment is in original OEM packaging with all components and consumables new and sealed as provided by the manufacturer. Some New & Boxed items stocked may actually be obsolete, and the warranty may not be full manufacturers, but will be stated on invoice (please ask if not clear).
New Open Boxed (NOB)	Equipment is in original OEM packaging and as-new condition. Consumables may not be included as some of these items may be ex-display. As some of these may actually be obsolete, the warranty may not be full manufacturers, but will be stated on invoice (please ask if not clear).
Refurbished	The dictionary definition of Refurbishment is - <i>the state of being restored to its former good condition</i> . A Refurbished 2 nd user printer will therefore be in A1 condition and with new parts (rollers, fusers, pads, covers etc.) as appropriate to bring it back to an as-new condition. Refurbished parts have new components (e.g. fusers with new rollers or sleeves) replacing the parts that wear out. If you are buying <i>Refurbished</i> make sure it is not just cleaned up!
Grade A	Second user equipment that is complete, cleaned, tested and generally serviced, with any apparent defective parts repaired/replaced as necessary to meet warranty requirements. Grade A units are in good cosmetic condition, allowing for normal usage and the age of the unit (some slight discolouration is normal on older printers). Grade A does not actually mean 'mint' or 'refurbished'.
Grade B	Second user equipment that is cleaned, tested and working, but may have cosmetic flaws, parts missing or minor problems which will be defined with the sale. This is a common grade for older printers where new plastic covers are unavailable or uneconomic to source at the price offered.
Grade C	Second user equipment that is sold as-is. May be working or not, but condition and terms will be stated with sale. Warranty is usually DOA (if working) or without warranty if not.
Pull	Used to describe a part or assembly pulled from a working unit for sale as a used spare part. Parts are usually cleaned, but not 'refurbished'.
Exchange Unit	Used to describe a basic printer unit without the peripheral parts (trays, external PSUs, dongles, consumables etc.) to be used to replace a faulty printer.
Consumables	Consumables are as defined by the manufacturer for specific printers, with the term usually encompassing toners, cartridges, ribbons, media, image transfer units and drums (refer to manufacturers' documentation for specific models). Once opened consumables do tend to deteriorate and therefore any used consumables provided are not normally covered by any warranty. Warranty on new consumables is as stated on the invoice. Used printers are often provided as standard without consumables ... please ask if unclear.
Distribution	Equipment manufacturers sell new equipment only through a small number of trade channels (Distributors) across Europe. Retailers (or authorised Re-Sellers) sell these to end-users and then administer (but rarely provide) warranty support, which usually is via an approved warranty provider in the country of sale.
RTB Warranty	RTB (Return To Base) Warranty is provided on the basis that the goods should be returned to us during the warranty period for examination. Repair or a replacement will be offered providing that the equipment returned is in the same condition provided (not tampered with) and failure was not attributable to wilful damage or caused by improper use.